


Drayton

How To Programme Your Drayton LP111



This new LP111 version has a Real Time Clock Module fitted and you will not need to set the day or time as this is automatically done for you.

In addition this new model now automatically adjusts itself for BST and GMT.

Important Note:

Before setting unit, press and hold the **“SET”** and **“+”** buttons for a minimum of **5 seconds** to **reset** to defaults (display will go blank)

How to set up required ON/OFF times

- Press **SET** button to display **“SET PROG”**
- Press **YES** button to display **“ON 6:30 AM”**
Press **“+”** or **“-”** to alter the first **ON** time
- Press **SET** button to display **“OFF 8:30 AM”**
Press **“+”** or **“-”** buttons to alter the first **OFF** time
- Press **SET** button to display **“ON 12:00 PM”**
Press **“+”** or **“-”** buttons to alter the second **ON** time
- Press **SET** button to display **“OFF 12:00 PM”**
Press **“+”** or **“-”** buttons to alter the second **OFF** time
- Press **SET** button to display **“ON 4:30 PM”**
Press **“+”** or **“-”** buttons to alter the third **ON** time
- Press **SET** button to display **“OFF 10:30 PM”**
Press **“+”** or **“-”** buttons to alter the third **OFF** time

PRESSING THE **SET** BUTTON, ONE MORE TIME AFTER PROGRAMMING, SETS THE PROGRAMMER TO AUTOMATIC OPERATION

Operating Modes

- Press **SELECT** Button for timing as follows

OFF = Continuously **OFF**
TIMED = Switching **ON/OFF** as programmed
ONCE = **ON** once from 1st ON to LAST **OFF**
ON = Continuously **ON**

Advance Button Function

- You can temporarily override the normal switching times by pushing the button marked "**ADVANCE**". When in timed mode this button switches "**ON**" to "**OFF**" or "**OFF**" to "**ON**" as you require, but the normal programme switching times will not be permanently affected.

What is a programmer?

...an explanation for householders

Programmers allow you to set 'On' and 'Off' time periods. Some models switch the central heating and domestic hot water on and off at the same time, while others allow the domestic hot water and heating to come on and go off at different times.

Set the 'On' and 'Off' time periods to suit your own lifestyle. On some programmers you must also set whether you want the heating and hot water to run continuously, run under the chosen 'On' and 'Off' heating periods, or be permanently off.

The time on the programmer must be correct. Some types have to be adjusted in spring and autumn at the changes between Greenwich Mean Time and British Summer Time.

You may be able to temporarily adjust the heating programme, for example, 'Override', 'Advance' or 'Boost'. These are explained in the manufacturer's instructions.

The heating will not work if the room thermostat has switched the heating off. And, if you have a hot-water cylinder, the water heating will not work if the cylinder thermostat detects that the hot water has reached the correct temperature.

Applicable Models

25473, 25474, 25475, 25476, 25477, 25478, 25490, 25491, 25492, 25493, 25494, 25600, 25601, 25602, 25603, 25620, 25621, 25622, 25623, 29101, 29102, 29103, 29104, 29205, 29206



Invensys Controls Europe

Customer Service Tel: 0845 130 5522

Technical Helpline Tel: 0845 130 7722

Email: customer.care@invensyscontrols.com

Website: www.draytoncontrols.co.uk