

# CRT - Battery Operated Room Thermostat

For use in normal environments.

**CURVE**



Before commencing any work on the electrical connections, you must first disconnect the device from the mains. None of the 230V connections must be live until the installation has been completed and the housing is closed. Only qualified electricians or authorised service staff are permitted to open the terminal box.



**Caution!** There are parts that carry mains voltage behind the cover. The terminal box must not be left unsupervised when open. (Prevent non specialists and especially children from gaining access to it.)



If this device is used in a way not specified by the manufacturer, it's safety may be impaired.

This thermostat can be mounted in the following ways:

1. To a recessed conduit box
2. To a surface mounted box
3. Directly mounted on wall

**Installation and connection should only be carried out by a qualified person and in accordance with national wiring regulations.**

