


How to comply with BS 7593:2019


A Quick Guide

Follow the six steps of the ADEY Best Practice approach using our proven products to meet the new British Standard (BS 7593:2019)


As even brand new systems may have debris they all should be cleaned with chemicals formulated for heating or cooling systems.




A flush should be completed on new systems and when repairing existing ones. Magnetite capture and radiator agitation can improve speed and effectiveness.



An inline filter should be fitted, after completing the clean, on all systems.



Chemical inhibitors should be added and anti-freeze should be used if the system is exposed to freezing temperatures. Biocides are important for systems running at below 60°C.



A water test is required to test the level of inhibitor and cleanliness of the system every year.



Inhibitors should be re-dosed every 5 years. A full lab test can be conducted to ensure ongoing protection.

